PO Box 255
Glenolden, PA 19036
T: 610.534.5550
F: 610.534.5552
info@simcosigns.com
www.simcosigns.com

Pounce Pattern Installation Instructions

Steps 2-3

Steps 4-5

1.) Measure wall area to determine placement of letters and/or graphics, logo, etc. Calculate where centerpoint of the area will be on the ***wall*** area. Using 3M® Blue masking tape, place tape at centerpoint (above or below where the pattern is going to be placed). This will allow center alignment with pattern. Make sure the area is clean by gently wiping entire surface with a clean dry cloth.

2.) Position the pattern onto the wall, using the centerline (marked on pattern) to align with the centerpoint referenced by the tape. Level pattern using either bottom of pattern, and/or level line drawn on pattern. Fasten in place using masking tape in all four corners and in the center as well (if pattern is unusually large, use more tape). For interior painted drywall, it is strongly suggested to use a paint-safe removable masking tape such as 3M® Blue (to avoid damaging wall surface).

3.) Double check the pattern for your centerpoint, height placement, and levelness. If needed, adjust the pattern by removing and reapplying the tape.

4.) Take the enclosed pounce bag, and tap it with firm pressure against the pattern, where you see the outline holes. Do this until the entire pattern has been “pounced” with the dust in the pounce bag. Once completed, rub the bag one final time over each outline to ensure everything was covered.

5.) Peel one corner of the pattern to make sure the image has transferred itself to the wall. If not, re-tape and repeat step 4.

6.) Remove pattern from wall. Peel tape off back of all letters/logos/elements, and position in place using the outline now visible on the wall. Continue until completed.

7.) Use the enclosed brush to ‘dust away’ the outlines around each of the letters until no dust is left showing.

8.) If you need any further assistance please give us a call at 610-534-5550 & we will be happy to assist you.

Step 6